


PKGO™

TAILGATE STAND FOR ORIGINAL PK GRILL + SMOKER™

ASSEMBLY INSTRUCTIONS

- Fits the Original PK™ Grill & Smoker capsule
- Great for camping, tailgating, and picnics
- Small footprint for use on any non-flammable surface
- Lightweight aluminum and stainless steel construction





GRILL CAPSULE NOT INCLUDED WITH STAND

DIMENSIONS IN INCHES




Ø1. SIDE VIEW

Ø2. TOP VIEW



Ø3. HINGED SIDE VIEW



Ø4. HANDLE SIDE VIEW

STAND PARTS LIST (IF NEEDED):






- 1) Left tube section
- 2) Right tube section
- 3) 2 bottom tube sections
- 4) 4 allen screws and 4 rivet nuts

GRILL CAPSULE PARTS LIST:

- 6) Grill lid capsule
- 7) Grill bottom capsule
- 8) Lid handle (plus hardware)
- 9) PK Original™ brand plate (plus hardware)
- 10) Hinged cooking grid
- 11) Charcoal grate

TOOLS NEEDED:

- 1) Allen wrench (included)




STEP
1

GO STAND ASSEMBLY STEPS:


Unpack box and lay out all parts.

1. Connect 1 bottom tube section into left tube section hole. Press allen screw up through the mated bottom hole and hold in place with finger. Then place rivet nut down through top hole to align with allen screw and hand tighten. Use allen wrench to tighten completely. Connect 2nd bottom tube section into other left tube hole and fasten using same process as above. Connect bottom tubes into right tube section holes and fasten using same process.




2) Place grill bottom capsule on PK-GO™ stand oriented as shown. Hinge side of capsule should be placed on left tube section.

Hinged Side




3) Place charcoal grate and hinged cooking grid inside grill bottom capsule.


Hinged Side




4) Assemble Original PK™ brand plate to grill lid capsule. Sawtooth washers go inside.




5) Assemble Lid Handle to grill lid capsule. Saw tooth and wedge washers go inside capsule.



6) Place grill lid capsule on top of grill bottom capsule. Open and close the lid once to ensure the hinge is properly seated.



7) Snap shelf wire lock bar over mount on grill bottom capsule to secure.



STAND USE & CARE

SEE ORIGINAL PK OWNER MANUAL FOR DETAILED GRILL USE INSTRUCTIONS AND SAFE USE WARNINGS.

- Always use PK-GO™ stand on a non-flammable surface.
- When grill is in use, always place an aluminum (or other non-flammable) tray under the Original PK™ bottom vents to catch any hot ash embers that may fall from bottom of bottom capsule.
- Use damp cloth and mild soap to clean PK-GO™ stand.

VISIT US AT PKGRILLS.COM FOR
PRODUCT INFORMATION, ACCESSORIES, RECIPE IDEAS & MORE.